

Instructions for Adaptor Kits

Remove current seat and any loose shims or additional separated plates.

Bolt adaptor plate to current bike post/plate using supplied nuts, bolts and washers. Use adjustable wrench to tighten nuts securely.

Insert or check to make sure the round post clamp is attached to seat rails. If not already installed, remove nuts and center connecting rod, separate individual parts and insert between rails as shown in instruction photos. Re-install connecting rod and both nuts. This process is displayed in photos on our web site at <http://www.derriair.com/adaptor-installation.htm>. You may need to rotate the center clamp to accommodate the adaptor plate.

Slide seat with black post clamp onto adaptor plate.

Rotate seat from side to side, front to back, and up and down, to position seat in proper position according to enclosed instructions. Seat should tilt very slightly down to the front.

Tighten nuts on both sides of post clamp until tight and seat does not move. Use a 14mm or 9/16" socket wrench to tighten the black nuts evenly on either side of black post clamp.

You should need to lower your large seat post 3 to 5 inches to accommodate the adaptor and new seat.

Tighten all nuts after 1 week to confirm tightness if necessary.

If you need assistance, please visit <http://www.derriair.com/adaptor-installation.htm> for photos and additional information.

Or call customer service Toll Free (888) 855-3545.

www.derriair.com info@derriair.com (888) 855-3545
PO Box 305 Rexford, MT 59930