The Hornless Seat Instructions

Determine which type of seat clamp you have, integrated clamp or separate clamp.

If you did not order a post clamp and find you need one – you can purchase one from your local bike shop or at Derriair.com.

INTEGRATED CLAMP INSTRUCTIONS:

You will need a 5 mm Allen wrench and a 14 mm box end wrench.

- 1. Loosen bolt on the underside of the seat to the point in which you can turn the upper portion of the clamp 90 degrees.
- 2. Lift off old saddle (bike seat).
- 3. Remove the clamp (if supplied) from your new Derri-Air bike saddle; your bike doesn't need this part. Use 13/14 mm wrench to loosen nuts.
- 4. Place your new seat on the bottom portion of seat clamp.
- 5. Rotate upper clamps back into place.
- 6. Set your desired seat angle, most find that a level seat is best.
- 7. Tighten Allen bolt.

SEPARATE CLAMP INSTRUCTIONS:

You will need only a 13 or 14 mm box type wrench.

- 1. Loosen one of the (13,14 mm) nuts on the side of the seat clamp to the point where you can wiggle your old seat off your bike.
- 2. Place your new seat on your new post.
- 3. Set your desired seat angle, most find that a level seat is best.
- 4. Tighten both nuts equally and securely.

SEAT ADJUSTMENTS:

Adjust the seat one inch (1") lower from your normal height to keep the hip to pedal relationship the same as before. This is because you are now sitting on your sit-bones and not up in your crotch. This is about a physical one inch difference. This is a starting point. Now adjust the seat forward or back, and tilt up or down to your comfort setting.

The Hornless Seat is a new sensation. Since you were a child all saddles had noses. Your first feeling will be that you are slipping off. This feeling will go away the more you ride. If you have drop-down handle bar you will load up your arms more.

Take advantage of our 30-day trial period to get used to your new seat and play with the adjustments. You will be rewarded with many years of comfortable and healthy cycling.

Need help? Call our excellent Customer Service Toll Free: (888) 855-3545

www.derriair.com info@derriair.com

PO Box 305 Rexford, MT 59930