

Comfort Seat Installation

Determine which type of seat clamp you have, integrated clamp or separate clamp.

If you did not order a post clamp and find you need one – you can purchase one from your local bike shop or at Derriair.com.

INTEGRATED CLAMP INSTRUCTIONS:

You will need a 5 mm Allen wrench and a 14 mm box end wrench.

1. Loosen bolt on the underside of the seat to the point in which you can turn the upper portion of the clamp 90 degrees.
2. Lift off old saddle (bike seat).
3. Remove the clamp (if supplied) from your new Derri-Air bike saddle; your bike doesn't need this part. Use 13/14 mm wrench to loosen nuts.
4. Place your new super soft seat on the bottom portion of seat clamp.
5. Rotate upper clamps back into place.
6. Set your desired seat angle, most find that a level seat is best.
7. Tighten Allen bolt.

SEPARATE CLAMP INSTRUCTIONS:

You will need only a 13 or 14 mm box type wrench.

1. Loosen one of the (13,14 mm) nuts on the side of the seat clamp to the point where you can wiggle your old seat off your bike.
2. Place your new seat on your new post.
3. Set your desired seat angle, most find that a level seat is best.
4. Tighten both nuts equally and securely.

Need help? Call our excellent Customer Service Toll Free: (888) 855-3545

ENJOY!

www.derriair.com info@derriair.com (888) 855-3545
PO Box 305 Rexford, MT 59930